

Instruction manual

5.7 Clamping System

The quick-release system allows a rapid pre-adjustment in order to avoid that depending on the size of the workpiece the clamping device must be rotated via the lengthy tension handle in position.

Turn the thumbscrew on (1).

Pre-adjust now the tensioner without threads in 3 different positions. Fixation is done with the threaded rod by turning the tension handle. (1 + 2)



1



2

WARNING: Before starting the machine, Please make sure that the material is clamped firmly.



Warning



Article ID: 600653

included adapter for
clamping of round and
square tubes

Ø 30mm - 70mm